



**COMMUNICATIONS
CENTRE**

Samsung Communications Centre
Unit 52, 5 Inglewood Place
Norwest Business Park
Baulkham Hills, NSW 2153
Tel: (02) 8818 3800 Fax: (02) 8818 3801
Service: 1300 655 522
email: service@samcomcentre.com.au
www.samcomcentre.com.au

Help Desk Document

SAMSUNG Digital Telephone System

Setting Time & Date

Access Customer Programming:

1. Press Transfer 200
2. Press 1234
3. Press 1 ("enable" displays on bottom line, handset now in program mode)
4. Press Transfer (LCD Screen resets to standard time and date)

Change the Time/Date:

1. Press Transfer 505
2. Enter new date then time as per the example below:
3. Press Transfer to save and exit.

OLD : 6010184 : 0047 NEW : WMMDDYY : HHMM
--

OLD : 6010184 : 0047 NEW : 3020994 : 1445
--

The display format is as follows:

W (Day of the week, 0-6) : eg, enter **0** for Sunday and **6** for Saturday
MM (Month, 01-12) : eg, enter **01** for January and **12** for December
DD (Day of the month) : enter a number in the range **01-31**
YY (Year) : enter the last two digits of the year eg 05
HH (Hours) : use the 24 hours clock and enter a number in the range **00-24**
MM (Minutes) : enter a number in the range of 00-59